

## **Scroll Saw Safety**

1. Unplug the saw before making any adjustments.
2. Keep your fingers away from the front of the saw blade and out of the cutting path at all times.
3. Turn the saw by hand before turning on the power. This ensures that the blade is not binding.
4. Push the stock forward rather than towards the sides.
5. Always wear safety glasses when operating the scroll saw.