Activity 1 – Building a Basic Robot

Vocabulary

- beam
- bracket
- · bronze bushing
- connector
- continuous rotation servo
- · Quick Rivet
- Quick Rivet Peg
- setscrew
- standard servo
- thumbscrew
- wing nut

Materials

- TETRIX PRIME Starter Set
- Painter's tape
- Stopwatch
- "Building a Basic Robot Data Sheet"

Objective

Learn how to build the Wheelee Bot using the Builder's Guide.

Procedure

- 1. Become familiar with the starter set.
 - A. Examine the metal and plastic parts.
 - B. Identify and inventory each element within the PRIME set using the top card from the set.
 - C. Think critically about why the parts are separated into storage bins and why this is a necessary step.
- 2. Follow the instructions in the *Builder's Guide* to assemble the Wheelee Bot robot. The Wheelee Bot is a three-wheel robot with one continuous rotation servo driving a wheel for propulsion and one standard servo providing the steering control.
- 3. After you have successfully assembled your robot, you need to connect the servos to the receiver. The drive servo should be plugged into channel 3 and the steering servo plugged into channel 1. This will enable you to move the joystick forward to move forward and sideways to turn.
- 4. If the servomotors do not move the robot in the same direction as the joystick movement, use the NOR/REV switches to change the direction of rotation.
- 5. Become familiar with the operation of the robot by operating the controls and driving it.

